

# DidyKlick®

## Carrying Instruction



Only use this carrier for  
children between  
3,5 kg and 20 kg.

# General Notes



## Starting position for all carrying methods



Pull the buckle through the safety loop ...



... with a click.



Slide the panel to the front and ...



... tighten the waistbelt at the loose end.


## Adjust the Width



With the carrier not on you, Lay your baby down onto the DidyKlick spread out flatly and ...



.... adjust the width from one hollow of the knee to the other.




Adjust the back part for smaller babies with the string and tie a knot. This is not necessary for bigger children.

### Tip

The position of the waist belt depends on the size of your child. For small babies, the waist belt sits under your lowest rib. For bigger babies, place it on your hip. This will ensure a comfortable position for you and your child.

## Adjustable Seat Width




The panel's width is adjustable.

## Adjustable Seat Height




The panel's height is adjustable with a drawstring.

## The Headrest



Adjust the size of the headrest with the string and the toggle.



Pull the button-down strap through the eyelet on the straps to adjust the height and fasten it.



Do the same on the other side.

### Notes

Never pull up the headrest to completely cover baby's head.  
Up to baby's ears is best to ensure sufficient air circulation.



# Front Carry

from birth



1



2



3




4



5



6



7



8



9



10


## Alternative



7



8



9



10

# Hip Carry



When your child has good head control



1




2




3



4



5




6



7



Alternatively




# Back Carry



When your child has good head control



1




2




3



4




5



6




7



8




9




10




11



12



13



14



15