

# DidySnap®

## Carrying Instruction



Only use this carrier for  
children between  
3,5 kg and 20 kg.

# General Notes



Starting position for all carrying methods

## Adjust the Width of the Panel



Lay your baby on the DidySnap panel and bring the waist belt up between baby's legs to the front.



Adjust the width to suit your baby's spread-squat position with fabric resting knee to knee.



Adjust the drawstring. Hold it in place with the toggle and tie with a bow.

## How to take your child out of the DidySnap



Loosen the strap first on one side and ...




... then on the other side.



Unfasten the buckle on your back while always holding your child securely.



Pull down one shoulder strap ...



... then the other one. Make sure to always hold and support your child with one hand.



Take your child out of the carrier before unfastening the waist belt.

# Front Carry



from birth



1



2




3



4



5



6



7




8



9



10



11



12



13



14



15




16



# Front Carry



Front Carry for Toddler with Torso Control.



1



2



3



4



5



6



7



8



9



10



11



12



13



14



15



16

# Back Carry



for Older Toddlers



1



2



3



4



5



6



7



8



9



10



11



12



13



14



15



16



17